

HOW DO I SET UP CERAMIC WELD BACKING?

Ceramic weld backing is an excellent option for supporting and shielding molten metal during welding operations. However, it must be set up and used properly to work as intended.

The process for using ceramic weld backing is as follows:

1

Remove the ceramic weld backing from its packaging

2

Size the ceramic weld backing to fit the joint

3

Remove the backing film from the adhesive sections of the ceramic weld backing

4

Apply the ceramic weld backing to the center of the joint

5

Create the weld on the front side of the joint

6

Allow the gas to disperse fully

7

Remove the slag

8

Remove the ceramic weld backing

GULLCO[®]

GULLCO INTERNATIONAL
WORLDWIDE WELDING AND CUTTING AUTOMATION

For questions about our KATBACK[®] ceramic weld backings, contact us today.

CAN: 905.953.4140 | sales@gullco.com | CAN: 905.953.4140 | ussales@gullco.com www.gullco.com

Authorised Distributor in New Zealand



www.arcweld.co.nz | sales@arcweld.co.nz | 0800 272 935